


# **M5 Quick Start Guide**




Thanks for choosing our product! This Quick Start Guide only applicable to M5. Before using the product, please read the Quick Start Guide to fully benefit from it.



No.	Part Name	No.	Part Name	
1	Power On/Off & Volume Knob	2	LCD Display	
3	LED Indicator	4	SOS Key	
5	Map Key	6	Speaker	
7	Microphone Jack	8	Microphone Programmable Keys	
9	Camera	10		

#### Programmable keys

For better using experience, you can install different PTT application and set P1, P2, P3, P4 as different functions with the help from PTT application provider according to your requirement.



No.	Part Name	
1	Antenna Port	
2	Power Port	
3	USB Port	

Programmable key	Function	LED Operating State	Indication
P1	PTT	Standby	Green(Blinking)
P2	Channel up	Searching Network	Green(Fast Blinking)
P3	Channel down	PTT Transmitting	Red(Steady)
P4	Programmable key	PTT Receiving	Green(Steady)



Telo Systems Tel: +86-755-86950766 E-mail: sales@telosystems.com Add: 4/F, Chuangye Building, Seven-Star Park, Yu'an 2nd Road, Bao'an District, Shenzhen, China. www.telosystems.com

## Note

Warranty period is 1 year from date of purchase

This product involves constant upgrading and/or improvement, our company reserves the right to change the specifications of software and/or hardware mentioned in this operating guide without any prior notice. The product specifications and information mentioned in the operating guide are for reference only

#### Check List

- 1 Radio Unit
- 2 Palm Microphone











(6) Mounting Bracket Kit



















## Notice

Please check the above accessories before you discard the packing material. Please contact your local dealer immediately if there is any missing or damage parts.


## Installation

- Before you install the radio in a vehicle, be sure to read the following instructions carefully.
- The radio operates with cathode-grounded power supply of 12 to 24V DC only.
- Please check polarity and voltage of the power supply on the vehicle
- Please check how long the screws will extend from the bottom surface of the radio, before you install the radio. Drill the mounting hole cautiously to avoid damage to the vehicle wiring and other parts.
- Please connect Telo Systems supplied antenna and power cord to the radio, before you install it in the bracket. And make sure the antenna and power cord is dedicated for Telo Systems digital radios.
- Install the radio with Telo Systems supplied mounting bracket, to avoid radio looseness in case of accidents. The loose radio may
- Install the radio in a location where it's easy to reach the front panel
- Please make sure there's sufficient space at back of the radio for
- When the fuse for DC power cord needs replacement, it must be replaced by a fuse with the same specification.

## Installation Tools

- Drill
- Cross-head screwdriver

## Installation Steps



- Install the Bracket in a location where it's easy to operate the radio
- Connect accessories such as antenna and power cord to the radio
- Slide the **radio** into the mounting bracket and secure it using the locking knobs.
- Install the microphone hanger in a location where it can be reached easily.
- nicrophone into the microphone jack on the front panel and place it on the hanger when you do not use it. Plug the palm microphone into the
- Nο Part Name Mounting Bracket Locking Knobs Antenna Cap

## Care and Cleaning

To guarantee optimal performance as well as a long service life of the product, please follow the tips below.

## Before Use

1. Insert SIM into M5 vehicular communicator and enable SIM data, or connect to a certain wifi/hotspot

2. Turn on the switch connects communicator with car hattery/circuit

# Product Care

- Keep the product at a place with good ventilation and heat dissipation to facilitate normal work
- Do not place irrelevant articles on top of the product to ensure optimal
- Do not place the product in corrosive agents, solutions or water.

#### **Product Cleaning**

- Clean up the dust and fine particles on the product parts with a clean and dry lint-free cloth or a brush regularly
- Use a non-woven fabric with neutral cleanser to clean the keys, control knobs, LCD and jacks after long-time use.
- Don't use chemical preparations such as stain removers, alcohol, sprays or oil preparations.
- Make sure the product is completely dry before use.

Caution: Power off the product before cleaning.